

Changes to the Build, Schematic, Parts, or Important Information Supplemental to the Build Manual and YouTube Build Series are located here.

1. Install J3 blue junction in reverse (with openings facing inside the board). When making up the ground wire from the DC jack and DC wire from the switch, make them long enough to swing over J3 and make the turn in. This will made installing these wires significantly easier!
2. Fan plug-in on the PCB is soldered in reverse from the label, we will place a black bar on the PCB indicating the side that the locking tab is to be installed on.

**Note: Always download the latest Addendum sheet available at [mellowtoneamps.ca](http://mellowtoneamps.ca) under the “Resources & Manual” download section for your amplifier.**